



DANDW60SG

60CM ELECTRONIC DISHWASHER



Features

- 14 place settings
- Electronic control , LCD display panel
- 7 wash programs -
intensive/normal/eco/glass/
- 1 hour express/rapid soak/half load
- 1-24 hours delay start
- Child lock
- 3 star energy rating / 4.5 star water rating

Accessories Included

- Third rack for cutlery,
- Adjustable basket

Power Specifications

- Voltage: 220-240V
- Power frequency: 50Hz
- Energy consumption cycle: 0.73 kWh
- Power consumption: 1760-2100W
- Water consumption: 10.8 liter
- Program duration: 185min
- Noise level: 54 dB(A) re 1 pW
- Water pressure: 0.04-1.0MPa=0.4-10 bar




Product Dimensions

598mm(W) x 600mm(D) x 845mm(H)

Installation Information

The installation of the pipes and electrical equipment should be performed by a qualified plumber. Check product dimensions before commencing installation. Disconnect water supply and electrical power before installing dishwasher. **FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY, DEATH OR ELECTRICAL SHOCK.**

Do not lift or install dishwasher by the door. Open the door and use the dishwasher cavity to lift and install the dishwasher.



Please note:

Dimensions and specifications are a guide only refer to the instruction manual for full instructions. Every effort has been made to ensure this information is correct. However, due to product improvement Daniela Appliances reserves the right to make changes to products without prior notice.